

POWERFLEX®

PART NUMBER

PFF60-1001

DESCRIPTION

FRONT WISHBONE BUSHES

INSTALLATION GUIDE

Contents (parts per pack):

8 x Polyurethane Bushes 4 x Zinc Plated Outer Shells
4 x Stainless Steel Sleeves 1 x PTFE/Silicone Grease
8 x Zinc Plated Washers

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.

Fitting Instructions:

1. Remove the original bush from the arm including its outer shell.
2. Clean any dirt or burrs from the bore of the arm, removing any sharp edges with a rounded file.
3. Press the zinc plated outer shell in from the inside of the arm until sitting flush, as shown in Fig 1.
4. Press the new bushes into either side of the outer shell.
5. Apply the supplied grease to the bore and the mounting faces of each bush.
6. Fit the stainless-steel sleeve into the bushes, shown in Fig 1.
7. Place the washer over each end of the sleeve.
8. Refit the arm to the vehicle and tension all hardware to the manufacturers recommended torque settings.

