

POWERFLEX®

PART NUMBER

PFR26-119

DESCRIPTION

REAR UPPER AND LOWER SPRING PADS

INSTALLATION GUIDE

Contents (parts per pack):

2 x Polyurethane A Bushes

2 x Polyurethane B Bushes

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.

Fitting Instructions:

1. Raise the vehicle using a trolley jack or a vehicle lift. Place axle stands under the vehicle if using a trolley jack.
2. Remove the rear wheels to gain access to the rear shock absorber lower bolt.
3. Support the rear lower suspension arm with a hydraulic jack to unload the suspension.
4. Remove the lower bolt from the rear shock absorber and carefully lower the supporting jack and rear suspension arm.
5. With the arm hanging down, remove the spring and spring pads and clean away any dirt from the spring and receiving surfaces on the chassis and arm.
6. Replace the OE rubber spring pads with the supplied Upper A Bush and Lower B Bush as shown in Fig 1.
7. Re-fit the spring and with the hydraulic jack, raise the arm until the lower shock absorber bolt hole aligns with the arm.
8. Re-fit the lower bolt and tension all hardware to the manufacturer's recommended torque settings.

